

## **Installation Instructions: Apache Offroad- Gusseted Jack Bracket**

### **Contents:**

- 2 Jack Brackets**
- 4 Allen head screws**
- 4 locking washers**
- 4 crossbar nuts w/ ball bearing**

### **Tools Needed:**

- Ladder**
- Towel or Piece of cardboard (Use as needed to protect your paint)**
- 5/32" Allen wrench**
- 3/4" Wrench or Socket**

### **Attention:**

Apache Offroad is not responsible for damages to the vehicle or injuries resulting from installing our products on a vehicle. Professional Installation and/or assistance is recommended for all installations. Please remember to wear eye protection.

Time Required: 30 min

People required: 1

- 1) If you have not done so already, install your Apache LoPro Rack.
- 2) Our crossbar nuts are able to be inserted any where along the crossbar. Slide two nuts into each bar and position them at the approximate width of the Tie Down Mounts. (Nuts will need to be slid in at an angle) (The ball bearing is spring loaded and will hold the nut in place while installing the mount) – The nuts need to be positioned short end to short end.
- 3) Position the jack bracket over the inserted nuts. Should be mounted one per bar, on the outside edge of the rack. The Jack is designed to sit right above the rail. For the FJ Cruiser position the bottom of the triangular upper bracket, even with the top bar of the factory rack. Repeat for second mount.
- 4) Install locking nuts on each screw
- 5) Tighten the screws, be sure to tighten the screws until the lock washer is fully compressed and the screws are tight.
- 6) Mount jack and tighten nuts with 3/4" wrench until tight